

6. Maintenance and cleaning :

In general it is not necessary to clean the modules if the inclination is $>10^\circ$. In case of persistent dirt use only classic glass cleaner or cleaning alcohol. Do not use galling or chemical cleaners, do not scrape the module.

All modules are maintenance free, but it could be useful to verify the PV-installation regularly against following criteria's:

- Integrity of the cables
- Fastening elements against e.g. loose brackets
- Cleanness, free of corrosion and safety connection of all cables connections

Administration:

SOLUXTEC SA
Route de Luxembourg, 74
L-6633 Wasserbillig
Luxembourg

Phone: +352-267410
Fax: +352-26741080

E-mail:
info@soluxtec.lu
www.soluxtec.eu

Production:

SOLUXTEC GmbH
Werner von Siemens Straße, 25
D-54634 Bitburg
Deutschland

Phone: +49 (0) 6561 6937 265
Fax: +49 (0) 6561 6937 268

E-mail:
info@soluxtec.de
www.soluxtec.eu